

POPCOKN POPPEK

38 Route 10 Westbound East Hanover, NJ 07936 973/887-7264 fax 973/887-0686 www.aPartyPleasing.com

INSTRUCTIONS

- 1. Turn all switches to "ON" position
- 2. First batch only allow kettle to heat up for four minutes
- 3. Add oil and then add the corn to the kettle being careful not to allow the plastic to touch the hot kettle.
- 4. Empty the kettle when popping is 99% complete, approximately 3 to 5 seconds between pops.
- 5. Repeat steps 3 and 4 for additional packs of popcorn.
- 6. On final batch only, turn kettle heat switch to "OFF" position as soon as corn starts popping rapidly.

CLEANING INSTRUCTIONS

1. When machine has cooled, empty un-popped kernels and wipe down inside of machine with a dry cloth.

WARNING

Keep kettle switch in "**OFF**" position when not popping Keep doors open when popping corn and closed when not popping corn.



RENTAL

POPCORN POPPER

38 Route 10 Westbound East Hanover, NJ 07936 973/887-7264 fax 973/887-0686 www.aPartyPleasing.com

INSTRUCTIONS

- 1. Turn all switches to "ON" position
- 2. First batch only allow kettle to heat up for four minutes
- 3. Add oil and then add the corn to the kettle being careful not to allow the plastic to touch the hot kettle.
- 4. Empty the kettle when popping is 99% complete, approximately 3 to 5 seconds between pops.
- 5. Repeat steps 3 and 4 for additional packs of popcorn.
- 6. On final batch only, turn kettle heat switch to "OFF" position as soon as corn starts popping rapidly.

CLEANING INSTRUCTIONS

1. When machine has cooled, empty un-popped kernels and wipe down inside of machine with a dry cloth.

WARNING

Keep kettle switch in "**OFF**" position when not popping Keep doors open when popping corn and closed when not popping corn.