



POPCORN POPPER

59 Newburgh Rd Box 608
Long Valley, NJ 07853-0608
908/850-0606 fax 908/850-0698
ElitePartyRentals.NET

INSTRUCTIONS

1. Turn all switches to "ON" position
2. First batch only – allow kettle to heat up for four minutes
3. Add oil and then add the corn to the kettle being careful not to allow the plastic to touch the hot kettle.
4. Empty the kettle when popping is 99% complete, approximately 3 to 5 seconds between pops.
5. Repeat steps 3 and 4 for additional packs of popcorn.
6. On final batch only, turn kettle heat switch to "OFF" position as soon as corn starts popping rapidly.

CLEANING INSTRUCTIONS

1. When machine has cooled, empty un-popped kernels and wipe down inside of machine with a dry cloth.

WARNING

Keep kettle switch in "OFF" position when not popping
Keep doors open when popping corn and closed when not popping corn.